HME

System 30 Drive-Thru Timer System

SUPPLEMENTARY OPERATING INSTRUCTIONS

Daylight Savings Time Adjustment for System 30 Timers

The following procedure describes how to adjust the System 30 Timer's clock to disable the automatic daylight savings time adjustment. Each time daylight savings time changes occur in your area, you must change the time setting in your System 30 Timer manually. Also, whenever the System 30 Timer is set to its factory default settings, you must check to be sure the **Daylight Sav:** setting is **NO**.

System 30 Timer software was designed to automatically adjust the times shown on reports when the **Daylight Sav:** was set to **YES**. This adjustment was set for the American Standard daylight savings time dates prior to 2007. Due to the change in those dates, effective 2007, it is necessary to disable the automatic adjustment by setting **Daylight Sav:** to **NO**, and manually changing the time whenever daylight savings time changes occur in your area.

NOTE: It is recommended that the clock adjustments be made while the store is closed, to avoid corrupting the timer's database. These clock adjustments affect the times recorded for data collection and printing of reports.

NOTE: If PC30 (PC interface program for System 30) is connected to the Timer and running, this adjustment can be made on your PC.

- 1. Press the SET UP SYSTEM key to enter the Set Up System Menus: display, and press the + or key until SYSTEM SETUP appears, then press ENTER.
- 2. In the System Setup: menu, press the + or key until SET DATE & TIME appears, then press ENTER.
- **3.** In the **Date/Time** menu, press **ENTER** or ! until you reach the **Time:** field, then press the number keys to carefully edit the hour setting to show the current time.
- 4. Press ENTER or ! until you reach the Daylight Sav: field.If YES is on the display, press the + or key until NO appears.

Set Up System Menus: <u>SYSTEM SETUP</u> Press + or - & ENTER

System Setup: <u>SET DATE & TIME</u> Press + or - & ENTER



- **5.** Press **ENTER** to accept the settings, then press **EXIT** to exit the menu.
- 6. Print a system settings report to verify the time settings you have made. (See back of this page.)

To print a system settings report:

- Press the SET UP SYSTEM key
 Set Up System Menus: display, and press the + or key until PRINT PROGRAMMING appears, then press ENTER.
- When the Print Programming: display appears, press the
 + or key until Print: SYSTEM appears, then press ENTER to print the system settings report.

Set Up	o S	yst	tem	M I	Menus:
PRINT	PR	OGF	RAM		[NG
Press	+	or	-	&	ENTER

Print Programming: Print: SYSTEM
Setup Listing Press + or - & ENTER